

# LIMESCALE WARNING!

- FAILURE TO DESCALE WILL CAUSE BLOCKAGES, PRODUCT FAILURE AND/OR VOID YOUR WARRANTY.
- DESCALE THE **CINO™ MILK STEAMER** IF THE **INDICATOR LIGHT** IS AMBER.
- USER MUST ONLY DESCALE THE **CINO™ MILK STEAMER** IN A WELL VENTILATED ROOM.
- A DROP IN PERFORMANCE OF THE STEAM OUTPUT INDICATES LIMESCALE HAS FORMED, USER MUST IMMEDIATELY DESCALE THE CINO™ MILK STEAMER.
- USER MUST DESCALE USING A SPECIFIC LIMESCALE REMOVING SOLUTION, COFFEE MACHINE CLEANERS WILL NOT DESCALE YOUR MACHINE.
- **ONLY USE DESCALER IN THE CINO™ MILK STEAMER WHEN IN DESCALE MODE.**
- SEE PAGE 13 OF THE INSTRUCTION BOOK FOR FULL DESCALE PROCEDURE AND FURTHER DETAILS.

Dualit recommends using **Kilrock-K limescale removing solution** (available at [kilrock.co.uk](http://kilrock.co.uk)). Follow the manufacturer's dosage and safety/handling precautions.



In certain hard water areas a descale cycle may be required before the Indicator Light turns amber. Please see water hardness map for the area where the product is used.

If there is no improvement in performance, or for a more thorough descaling, please repeat the procedure specified on page 13 of the instruction booklet.

