IOL Soup Kettle

Instruction Manual & Guarantee

MPORTANT SAFETY PRECAUTIONS

READ ALL INSTRUCTIONS

Before using the soup kettle keep these Instructions for future reference

IMPORTANT SAFEGUARDS

• I his appliance must not be used by children younger than 8 years old and persons with very extensive and complex disabilities. Children aged 8-14 years and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge shall not use this appliance, unless they are supervised and have been given instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children less than 8 years old.

Electrical safety

- Before plugging in, check that the voltage on the rating label is the same as the mains supply.
- We recommend that the soup kettle is plugged into a socket that has no other appliance connected to it. Failure to do this may cause an overload, trip a circuit breaker or blow a fuse. Preferably the socket should be protected by a Residual Current Device (RCD).
- Unplug from outlet when not in use. Allow to cool before cleaning and before putting on or taking off parts.
- To protect against electric shock, do not immerse any part of this product in water or other liquid.
- NOTE: Any plug cut from power supply cord should be disposed of immediately. Inserting any cut off plug into a 13A socket-outlet is hazardous.
- Do not operate any appliance with a damaged lead or plug, or after the appliance malfunctions or has been damaged, cracked or dropped in any manner.
- If the power cord is damaged it must, for safety reasons, be replaced by Dualit or an authorised Dualit repairer.
- Never use the plug without the fuse cover fitted. Ensure replacement fuse is the same current value as original.
- Replacement fuses should be ASTA approved to BS 1362.
- WARNING: This appliance must be earthed.

General safety

- Do not place the soup kettle or mains lead on or near any hot surface, hot hob, gas burner or in a heated oven.
- Do not allow cable to touch hot surfaces, or to hang over edge of a table or counter top.
- Do not use appliance for any purpose other than the intended use.
- Do not use if dropped, cracked or damaged.
- Parts or surfaces of the soup kettle will get hot during use.
- Do not touch hot surfaces, move or carry the soup kettle when hot or full.
- The use of accessory attachments not recommended by Dualit may result in fire, electric shock or injury to persons.
- Do not store or use in an appliance garage, under cupboards, near curtains or flammable material. A fire may occur if incorrectly postioned.

- Position main body on an open, level surface and ensure the soup kettle is at least 200mm clear from overhanging cupboards and walls.
- Do not operate on an inclined plane.
- Do not use outdoors.
- A short power-supply cord is to be provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
- Keep the soup kettle empty when not in use. Do not operate the soup kettle empty.
- The food item must be heated prior to using the soup kettle. The kettle is designed to keep food warm, not for cooking
- Never move or carry the soup kettle when unit is switched on, or containing food.
- Do not overfill.
- Always operate with lid in place.
- Appliance should not be installed in an area where a water jet could be used. Appliance must not be cleaned by water jet.
- Appliance should be used in an area where it can be overseen by trained personnel.
- Check the water level every 15 minutes to ensure it is between the minimum and maximum mark. Refill as necessary.
- This is a WET HEAT ONLY kettle, a small amount of water is required between the inner and outer liner in order to operate.

SAVE THESE INSTRUCTIONS


In the interest of improving products, Dualit Ltd. reserves the right to change the product specification without prior notice. All illustrations are for representation only, your model may vary from illustrations shown.

INSTRUCTIONS ON ENVIRONMENT PROTECTION



Do not dispose this product in the usual household garbage at the end of its life cycle. Please hand it over to a collection point for the recycling of electrical and electronic appliances. The symbol on the product, the instruction of use or the packaging will inform you about the methods of disposal. The materials are recyclable as mentioned on its marking. By recycling, material recycling or other forms of re-utilization of old appliances you are making an important contribution to protect our environment. Please enquire at the community administration for the authorised disposal location.

KNOW YOUR SOUP KETTLE





Dualit



SETTING UP

Thoroughly wash the stainless steel liner and lid in warm soapy water.

Do not store or use in an appliance garage, under cupboards, near curtains or flammable material. A fire may occur if incorrectly postioned. Position main body on an open, level surface and ensure the soup kettle is at least 200mm clear from overhanging cupboards and walls.

Place collar on top of main body.

Hold the hinge on the lip of the collar, as shown on diagram overleaf.

Insert the stainless steel liner into the main body. Once assembled the liner will hold the collar and lid in place.

Plug unit into correct electrical socket.

This appliance is suitable for **wet heat operation only.**

Add a minimum of 300ml - maximum of 600ml of water between the stainless steel liner and internal aluminium container in the main body. Check every 15 minutes and refill if water level gets low, do not let it evaporate and heat empty.

Never overfill with water. Remove any excess water immediately.

Carefully add your already heated food items into the stainless steel liner.

To turn on, rotate the temperature knob clockwise to the desired setting. The heating/ready will then come on.

Always operate the soup kettle at the lowest possible temperature in order to minimise electricity costs.

Once the desired temperature is reached the light will go out.

Actual operating temperatures vary depending on; type and volume of food being kept warm, ambient air temperature, lid in place or removed, and ventilation.

It is the users responsibility to ensure food being served is kept warm at the correct temperature.

Attach the soup of the day label, insert the name card into the magnetic holder. Fix holder anywhere on the exterior of the main body.

To switch off, turn the dial to '0'. Unplug from the wall socket to isolate kettle from the electrical supply.

Always keep the removable hinged lid attached and in the closed position when not serving.

Never move or carry the kettle when unit is switched on, or containing food. Switch off, unplug and disassemble before cleaning.

CLEANING & CARE

Switch the soup kettle off, remove the plug from the wall socket and let the soup kettle cool down before you start cleaning it. Do not let the main body, flex or plug get wet. Wipe the outside of the soup kettle with a soft moist cloth and dry it with another cloth. Spilled food should be removed immediately from all exterior surfaces. The stainless steel bain marie and lid are machine washable. The soup kettle must not be cleaned with a high pressure jet.

GUARANTEE

This appliance is of excellent quality and construction. However, if any defects in materials or workmanship do appear during the relevant guarantee period, we will, at our discretion, either repair or replace the defective parts, free of charge, subject to the terms and conditions of our Guarantee shown below.

This Guarantee covers both parts and labour. Carriage is not included.

Your Guarantee period is as follows:

• I year

This Guarantee provides benefits which are additional to, and do not affect, your statutory rights. This Guarantee does not cover the cost of returning the product to the dealer from whom it was purchased or to ourselves. This Guarantee applies only to products sold and located in mainland Great Britain. It does not cover liability in respect of or replacement of plugs, cables or fuses and also does not cover defects due to:

- Failure to use or maintain product in accordance with Dualit's instructions.
- The product being connected to an unsuitable electricity supply.
- Accidental damage to or abuse or misuse of the product.
- Product modification, except by Dualit or approved agent.
- Dismantling of or interference with the product.
- Theft or attempted theft of the product.
- Before returning any product under this Guarantee, please check that:
- You have followed the product instructions correctly.

- Your mains electricity supply is functional.
- The defect is not due to a blown fuse.
- If you wish to claim under this guarantee you should:
- Send the product, postage or carriage paid, to the dealer from whom it was purchased or to Dualit direct.
- Ensure that the product is clean and packed carefully (preferably in its original carton).
- Enclose details of your name, address and telephone number and when and where the product was purchased, together with proof of purchase (e.g. a till receipt).
- Give exact details of the nature of the defect.

This Guarantee does not cover any other claims whatsoever, including, without limitation, any liability for incidental, indirect or consequential damage, nor does it cover any claims for conversion or modification or for the costs of repair carried out by any third party without the prior consent of Dualit. If replacement parts are fitted to the product this will not extend the period of the Guarantee.

For further advice contact the Dualit customer helpline on +44 (0)1293 652 500 (09:00 to 17:00 Monday to Friday).

Alternatively, email Dualit at info@dualit.com or visit www.dualit.com



Dualit Limited County Oak Way Crawley West Sussex RH11 7ST • t: +44(0)1293 652 500 f: +44(0)1293 652 555 e: info@dualit.com www.dualit.com